

**ID-4261 CCD Indoor Dome Camera**



**Installation Manual**

Sony High-Resolution Infrared IR  
Indoor Dome Camera w/420 TVL  
w/ 4-9mm Varifocal Lens

## **Camera Installation**

### **Camera Setup:**

#### **Items Needed:**

Screwdriver, Drill, Mounting Hardware (not included), Glove or Cloth for removing Dome, Pencil

- a. Remove Mounting Plate and mount plate to wall using appropriate screws



- b. Depress button on back of camera, then remove the dome cover.



- c. Mount camera base to mounting plate

## **Camera Installation**

- d. Connect Cables



Top = BNC Video Connector  
Bottom = Power Connector

- e. Adjust Zoom and focus of lens



- f. Adjust camera angle to suit needs  
g. Reinstall Dome



<b>ID-4261 CCD Color Dome Camera</b>	
Image Sensor	Sony 1/3" CCD Sensor
Number of Pixels	NTSC: 510 (H) x 492 (V)
Lens	4-9mm Varifocal Lens
Sync System	Internal Synchronization
Resolution	420 TVL
Dimensions	127mm (D) x 95mm (H)
Video Output	1.0Vp-p75Ω
S/N Ratio	>48 dB
IR Illumination	Up to 65' in No-Light Conditions
Operation Temp.	-10°C ~ +45°C
Storage Temp.	-30°C ~ +60°C
Useable Illumination	0.01 Lux (F:1.2)
Power Source	DC 12V 350mA

<b>Installation Notes</b>
<ul style="list-style-type: none"><li>• For Indoor Use Only</li><li>• Disassembly of camera is not recommended</li><li>• Handle lens carefully with gloves to prevent damage from oil on your hands</li><li>• Handle with care</li><li>• To prevent shock, do not plug in camera with dome removed</li><li>• Never touch lens directly</li><li>• Clean the dome occasionally with a dry micro-fiber cloth, or plastic cleaner only – Do not use abrasive-type cleaners as they will scratch dome</li></ul>